



A National Distributor Providing Installation and Technical Support for  
Voice, Data, Video, and Security  
952/894-1984 • [www.mntelephone.com](http://www.mntelephone.com)

## **WIN** including 24D, 36D, 36DX, and 100D

Note: The time can only be set from an assigned display phone or Station 10. On a WIN 100D, time is to be set from the Receptionist phone. Performing this operation will adjust the time setting on all display phones.

1. Press **FEAT** button
2. Dial **32**
3. Dial **4 Digit Hour**
4. Dial **\*** for AM or Dial **#** for PM
5. Press **FEAT** button
6. Press **HF** button